

## DISA

PART NO	DESCRIPTION
1082102	BONNET
1082104	PLUNGER
1086631	BARREL
1P7324	GLOW PLUG
1P3409	PUMP
1P6400	PLUNGER&BAREL
1W6541	PLUNGER
1W3010	PUMP
1W6539	PUMP
1W6987	VALVE
1W9171	BONNET
2S1631	CHECK
2S7264	PUMP
3F0305	CHECK
3H2033	GLOW PLUG
3S1467	PUMP
3S6638	SERVICE GRP.
3S8336	PLUNGER
3S9624	GLOW PLUG
3T8705	PLUG
3T8706	PLUG
4N0184	FLYWHEEL
4N0209	BONNET
4N0406	GEAR
4N0429	GEAR
4N1767	VALVE
4N2954	SLEEVE
4N4997	PLUNGER & BARREL
4P9830	PLUNGER
4S5758	PLUNGER
4W0788	PUMP
4W7015	NOZZLE
4W7016	NOZZLE
4W7017	NOZZLE
4W7018	NOZZLE
4W7019	NOZZLE
4W7022	NOZZLE
6N7527	PUMP
7M7431	SERVICE GRP
7N0449	NOZZLE
7N1183	PLUNGER
7N9843	NOZZLE
7W0182	PLUNGER
7W5929	PLUNGER
7W7026	NOZZLE
7W7032	NOZZLE
7W7037	NOZZLE
8M1584	SERVICE GROUP
8N1317	LIFTER
8N1414	CHECK
8N1415	SPRING
8N1417	BONNET
8N2516	BONNET
8N1831	NOZZLE
8N3175	NOZZLE
8N7005	NOZZLE
8N8796	SERVICE GROUP
9B1320	VALVE CHECK
9H5746	CHECK
9H5797	PLUNGER
9L6863	BODY
9L6969	NOZZLE
9L6884	NOZZLE

---

All producers names, machine models and part numbers stated in our list are only for reference use.  
Parts are imported by AES Trading.

**MISSING PRODUCTS IN AES CATALOGUE**

<b>SERIES</b>	<b>P/N</b>	<b>DESCRIPTION</b>	<b>PRICE?</b>	
<b>C A T  P L U N G E R  A N D  B A R R E L S</b>	142-2812	PUMP ASSEMBLY		
	142-2818	PUMP ASSEMBLY		
	4S 7913	P&B		
	7N 1220	P&B		
	7S 6681	P&B		
	8N 3539	P&B		
	8S 3656	P&B		
	9H 5796	P&B		
	9L 4102	P&B		
	3D 2993	SEAL O-RING		
	4D 3107	SEAL O-RING		
	4N 0223	SEAL O-RING		
	6F 6672	SEAL O-RING		
	7C 9966	SPHERICAL INSERT		
	1S 8634	CHECK VALVE SPRING		
	3F 0303	CHECK VALVE SPRING		
	6N 0024	CHECK VALVE SPRING		
	8N 5993	CHECK VALVE SPRING		
	9B 1363	CHECK VALVE SPRING		
	9L 9424	CHECK VALVE SPRING		
	9S 0097	CHECK VALVE SPRING		
	9L 6892	COLLAR		
	4N 2655	CHECK VALVE		
	8S 4175	CHECK VALVE		
	7N 1410	CHECK VALVE		
	7N 5148	CHECK VALVE		
	9L 6889	CHECK VALVE		
	9N 0593	CHECK VALVE		
	4P 7688	CHECK VALVE		
	4P 9258	CHECK VALVE		
	<b>C A T  N O Z Z L E S</b>	7M 4601	CAPSULE NOZZLE	
		8N 1831	CAPSULE NOZZLE	
		8N 3173	CAPSULE NOZZLE	
8N 3176		CAPSULE NOZZLE		
8N 4694		CAPSULE NOZZLE		
8N 4697		CAPSULE NOZZLE		
8N 5986		CAPSULE NOZZLE		
9F 4113		CAPSULE NOZZLE		
6F 1069		SEAL		
5B 3718		SEAL		
5H 7936		SERVICE GROUP		
6H 3364		SERVICE GROUP		
7S 9891		SERVICE GROUP		
9F 2393		SERVICE GROUP		
8N 3177		CAPSULE NOZZLE		
9N 6173	CAPSULE NOZZLE			

	9N 3246	CAPSULE NOZZLE	
C A T I N J E C T O R	170-5187	NOZZLE ASSY 7000 SERIES	
	170-5181	NOZZLE ASSY 7000 SERIES	
	8N 7003	NOZZLE ASSY 7000 SERIES	
	100-7559	NOZZLE ASSY 7000 SERIES	
	170-5181	NOZZLE ASSY 7000 SERIES	
	170-5187	NOZZLE ASSY 7000 SERIES	
	4W 7020	NOZZLE ASSY 7000 SERIES	
	4W 7026	NOZZLE ASSY 7000 SERIES	
	7W 7040	NOZZLE ASSY 7000 SERIES	
	7W 7043	NOZZLE ASSY 7000 SERIES	
	100-7556	NOZZLE ASSY 7000 SERIES	
	100-7558	NOZZLE ASSY 7000 SERIES	
	130-1804	NOZZLE ASSY 7000 SERIES	
	130-5187	NOZZLE ASSY 7000 SERIES	
	1W 5829	PENCIL NOZZLE ASSY	
9N 2366	PENCIL NOZZLE ASSY		
C A T I N J E C T I O N P U M P S A N D	8M 2667	PUMP ASSEMBLY	
	8M 3138	PUMP ASSEMBLY	
	8M 3280	PUMP ASSEMBLY	
	8M 9753	PUMP ASSEMBLY	
	8M 9755	PUMP ASSEMBLY	
	8M 9758	PUMP ASSEMBLY	
	108-6630	FUEL INJECTION PUMP GROUP	
	49 9827	FUEL INJECTION PUMP GROUP	
	7W 0561	FUEL INJECTION PUMP GROUP	
	6N 1042	FUEL INJECTION PUMP GROUP	
	6N 1043	FUEL INJECTION PUMP GROUP	
	6N 7829	FUEL INJECTION PUMP GROUP	
	7N 1185	FUEL INJECTION PUMP GROUP	
	7N 1219	FUEL INJECTION PUMP GROUP	
	7W 0561	FUEL INJECTION PUMP GROUP	
	7W 5928	FUEL INJECTION PUMP GROUP	
	108-6633	FUEL INJECTION PUMP GROUP	
	108-6634	FUEL INJECTION PUMP GROUP	
	4N 8898	FUEL INJECTION PUMP ASSY	
	9Y 0510	FUEL INJECTION PUMP ASSY	
	7C 8927	FUEL INJECTION PUMP ASSY	
	7N 5301	FUEL INJECTION PUMP ASSY	
	8N 4997	FUEL INJECTION PUMP ASSY	
9N 5827	FUEL INJECTION PUMP ASSY		
9Y 0510	FUEL INJECTION PUMP ASSY		
9Y 9246	FUEL INJECTION PUMP ASSY		
133-8984	FUEL INJECTION PUMP ASSY		
C A T O R S	7E 3399	P&B ASSY	
	7C 0340	CAPSULE NOZZLE	
	7C 0344	CAPSULE NOZZLE	
	7C 2238	CAPSULE NOZZLE	
	9Y 0051	CAPSULE NOZZLE	
C	5H 7225	NUT	

C A T  M I S C E L L A N E O U S	7M 4603	BODY	
	8S 2389	BODY	
	4N 2484	BONNET	
	6I 1327	BONNET	
	7W 8039	BONNET	
	8S 3653	BONNET	
	9L 6893	BONNET	
	6N 6794	LIFTER	
	1P 2298	VALVE ASSEMBLY	
	6N 1716	VALVE ASSEMBLY	
	4N 0434	RISER	
	9H 2256	PRIMER PUMP ASSEMBLY	
	4N 1132	TRANSFER PUMP HOUSING FOR 3208	
	1W 1695	<b>FUEL TRANSFER PUMP (NEW)</b>	
	1W 1700	<b>FUEL TRANSFER PUMP (NEW)</b>	
	1W 5910	<b>TAPPET ASSY FOR 1W 1700 (NEW)</b>	
1W 5912	<b>TAPPET ASSY FOR 1W 1695 (NEW)</b>		
C A T  P L U G  G L O W	3T 9561	GLOW PLUG	
	3T 9562	GLOW PLUG	
	4N 0360	GLOW PLUG	
	4S 7824	GLOW PLUG	
	6N 1058	GLOW PLUG	
	9N 0194	GLOW PLUG	
	ZD-1A	GLOW PLUG	
	ZD - 9	GLOW PLUG	
	ZD - 11	GLOW PLUG	
ZD - 13	GLOW PLUG		